

Service Documentation

Service Information No. 50/2009

LWL/KDT-baj/30.01.10

Error message "Eht"

Models: GKPv ..20/70 from index 11D

BKPv 65/84.. from index 10D GGPv ..20/70 from index 16D BGPv 64/84.. from index 15D

all versions

Fault profile: The electronics indicate error message "Eht" and the compressor no longer

switches on.

Cause: The "Eht" (evaporator high temperature) error message means that the

evaporator has become too hot (hotter than +60°C). The compressor is

switched off to avoid consequential damage.

Possible causes include: - solenoid valve does not close

- evaporator sensor is signalling the wrong value

To correct: Diagnose appliance and replace defective component.

Note: To acknowledge the message the appliance must be switched off by

pressing the On/Off button and the mains plug pulled out.