

Service Documentation


Service Manual No. 24/2014

LWL/KDT-baj/24.07.14

Appliance Documentation

GGU 15.. from Index 21

Commercial freezer, suitable for under-worktop installation










Contents


1.0 Operating and control elements	3
1.1 Control elements	3
2.0 Functions at a glance	4
3.0 Description of appliance	5
3.1 Sensor position	5
4.0 Main components and their functions	6
4.1 Electrical components and functions	6
4.2 Refrigeration components and functions	7
5.0 Assembly instructions / Parts replacement	8
5.1 Electronics	8
5.2 Air sensor	10
5.3 Door magnet	10
6.0 Technical data	11
7.0 Service menu	12
7.1 Brief overview of service menu	12
7.2 Demo mode	13
7.3 Panel test	13
7.4 Sensor test (temperature display)	14
7.5 Service mode	14
8.0 Table of error codes	15

1.0 Operating and control elements



- 1 ON/OFF button
- 2 SuperFrost function
- 3 Temperature display
- 4 Temperature setting button
- 5 Alarm OFF button for audible alarm

1.1 Control elements



- 1 Demo mode active
- 2 Temperature alarm active
- 3 SuperFrost switched on
- 4 Child lock active
- 5 Service mode active
- 6 Temperature too high due to power failure

2.0 Functions at a glance


Control:	Electronics
Temperature display:	Actual value
Temperature range:	-9°C to -26°C
Temperature alarm:	Visual and audible
Door alarm:	Audible
Fan:	Not featured
Defrosting:	Manual
Interior light:	Not featured
Service menu:	Featured
Compressor:	Standard
Solenoid valve cooling circuit:	Not featured

3.0 Description of appliance

The GGU 15.. models are statically cooled freezers with wire tube evaporator. Because of the low appliance height of 83cm, the models are also suitable for under-worktop installation!

The temperature is controlled by an air sensor.

3.1 Sensor position



4.0 Main components and their functions

4.1 **Electrical components and functions**

Electronics

Type: Series 6 electronic control system

Integral PCB Components:

Setting range: -9° C to -26° C

Display range: -32°C to -1°C

Functions

SuperFrost: <u>SuperFrost activated (quantity-controlled):</u>

> The appliance is set to a notional target value (11°C colder than target value, but to a maximum of -32°C, i.e. compressor runs almost continuously) and switches off earlier (min. 30 hours) or later (max. 65 hours) depending on the stored quantity.

SuperFrost deactivated:

The appliance sets itself to the set value.

-9°C to -22°C Temperature alarm: When: Target value:

> Alarm value: 4K warmer than target value.

-25°C and -26°C Target value:

Alarm value: -20°C SuperFrost alarm value: -20°C.

Audible: 4 beeps (suppressed upon start-up)

Visual: flashing temperature display

Alarm is output with a 60-minute delay when the air sensor has reached the alarm value (e.g. set value: -18° C, actual value at -14° C for 60 minutes → alarm).

On start-up, the temperature display flashes until the switch-off value is reached,

the audible alarm is suppressed.

Door alarm: When: Door open for longer than 3 minutes.

> Audible: 3 beeps

Activation is via the customer menu. Child lock:

- When the child lock is activated, the ON/OFF button and the temperature setting

button are inactive.

- The remaining functions are available for unrestricted use.

Defrosting: Manual

Sensors

Position: Clipped in behind the 2nd. evaporator level. Air sensor:

> Function: Switches the compressor ON and OFF.

Switches

Door switch: Position: In front panel.

> Type: Semi-conductor component on the PCB

Contact type: Closing mechanism

Function: Activation via magnet on the door, magnet is interchangeable.

Switching signal when:

Door closed: Door alarm **OFF** ON

Door open: Door alarm

Consumers / Loads

Compressor: Function: ON: Air sensor switch-on value.

> OFF: Air sensor switch-off value.

Special features: On-delay time (8 min.) must

have elapsed.

4.2 Refrigeration components and functions

Compressor: 1 standard compressor, R600a

Evaporator: Wire tube evaporator. Type of appliance:

> Type of installation: Between baskets or drawers

Injection point: Top

Flow sequence: From top to bottom.

Frame heater: Position: Foamed in in the frame area.

> Type: Fluid heater

Condenser: Type of appliance: Lamellar condenser

> Type of installation: Freely suspended at the rear

Assembly instructions / Parts replacement 5.0

5.1 **Electronics**

Front panel:

- Remove screws (Fig. 5.1/ 1). - Pull down front panel and disconnect cables (Fig. 5.1/ 2 and Fig. 5.1/ 3).




Fig. 5.1/1



Fig. 5.1/ 2



Fig. 5.1/ 3

PCB holder: - Unclip PCB holder from front panel.



Fig. 5.1/ 4

Cover: - Unclip cover.



Fig. 5.1.1/ 5




Fig. 5.1/ 6

All individual parts:



Fig. 5.1/ 7

5.2 Air sensor

Air sensor:

- Take the sensor out of the holder (note position) and thread it out through the rear wall.
- When installing, take care to ensure that the sensor is clipped into the right position (Fig. 5.2/ 2)
- After the sensor cable has been foamed into the worktop, the new sensor must be bonded on the reverse (instructions included with new sensor!).






Fig. 5.2 / 1

Fig. 5.2 / 2

5.3 Door magnet



Magnet: - Pull out magnet.



Fig. 5.3 / 2

6.0 Technical data


Sensor values:

Air sensor

Temperature [°C]	Resistance value [kOhm]
+35	3.1
+30	3.8
+25	4.7
+20	5.9
+15	7.3
+10	9.3
+5	11.9
0	15.3
-5	19.8
-10	25.9
-15	34.1
-20	45.3
-25	60.8
-30	82.3
-35	112.8

7.0 Service menu

The service menu may only be used by service technicians.



Activate service menu:

Press

Appliance must be switched on. "ON/OFF" + "Up/Down" simultaneously for approx. 5 seconds

Brief overview of service menu 7.1

Service menu	Menu	Action	Submenu	Action	Function elements selection	
Demo mode		1x SF	90	1x SF	Demo mode OFF	
	₹		8		Demo mode ON	
Panel test (operating	→	1x SF	P	1x SF	Press sensor buttons	
Sensor test	wn buttor	1x SF	88	1x SF	: Air sensor : R : Door contact	
Service mode	Up/Down	1x SF	88	1x SF	Up-/ Down Button 1 : All OFF : Compressor ON	

7.2 Demo mode

Step	Display	Action	Display following action	Testing option / Info	
Start ser	vice menuDemo r	node ON		SF = SuperFrost	
1	Actual value	Press " Up/Down " and " ON/OFF " simultaneously for 5 seconds	flashes	Demo mode selected	
2	flashes	Press "SF" once	static	Demo mode ON selected	
3	static	Press "SF" once	Set target value and "Demo"	Demo mode ON	
Start ser	Start service menuDemo mode OFF				
1	Target value and "Demo"	Press "Up/Down" and "ON/OFF" simultaneously for 5 seconds	flashes and "Demo"	Service menu active	
2	flashes and "Demo"	Press "SF" once	static and "Demo"	Demo mode OFF selected	
3	static and "Demo"	Press "SF" once	Actual value	Demo mode OFF	

The text "Demo" in the display indicates the activated demo mode.

Demo mode can only be deactivated via the service menu, not by OFF/ON or disconnection from the power supply.

Operation switches to the desired mode, either demo mode or normal mode, as soon as "SuperFrost" has been pressed.

7.3 Panel test



Step	Display Action Display following action		Display following action	Testing option / Info
Start service	e menu			SF = SuperFrost
1	Actual value	Press " Up/Down " and " ON/OFF " simultaneously for 5 seconds		
Operating e	lement test test	of sensor buttons, display eleme	ents, door sensor a	nd beep
2	flashes	Press "Up/Down" once	P flashes	Panel test selected
3	P flashes	Press "SF" once	P static	Panel test activated
4	P I static	Press "SF" once	All symbols/segments	Display elements/ More symbols are displayed than are used by the respective electronic control system!
5	All symbols and segments	- Press all buttons in sequence (every operation is acknow- ledged by a beep) - Door open/closed	- Beep for 2 seconds - Appliance switches OFF	Beep sounds only when test was successful.
Operating element test cannot be terminated, e.g. in step 2, it has to be performed in full. Termination If a button is defective, no beep is output for 2 sec and the appliance does not switch off. The appliance then has to be unplugged and plugged back in again.				

7.4 Sensor test (temperature display)



Step			Display following action	Testing option / Info
Start service	menu			SF = SuperFrost
1	Actual value	Press "Up/Down" and "ON/OFF" simultaneously for 5 seconds	flashes	Service menu active
Sensor test	and door contact te	est (sensor values without offse	et, appliance in contro	l mode)
2	d flashes	Press "Up" twice	E - flashes	Sensor test mode selected
3	E - flashes	Press "SF" once	E 'static	Sensor test mode activated
4	static	Press "SF" once	Flashes alternately with sensor temperature	Air sensor
	Flashes alternately with sensor temperature		flashes alternately with	Door contact (oP=Door open, cL=Door closed)
Press "ON/OFF" once: Return to level 2 [. No further items are selectable with this appliance. Press "ON/OFF" twice: Return to level 1 [Points: d, P, E - , L selectable Press "ON/OFF" three times: Return to normal/control mode				

7.5 Service mode

Step	Display	Action	Display following action	Testing option / Info	
Start service	e menu			SF =	SuperFrost
1	Actual value	Press "Up" and "ON/OFF" simultaneously for 5 seconds	flashes	Service menu active	
Service mod	de testing	electric loads			Power input
2	d flashes	Press "Up" three times	flashes	Service mode selected	
3	flashes	Press "SF" once	static	Service mode activated	I
5 → 4	static	Press "SF" once	static	All OFF	
5	static	Press "Up" once	static	Compressor ON	Approx. 90 W
Terminatio n Press "ON/OFF" once: Return to level 2 . No further items are selectable with this appliance. Press "ON/OFF" twice: Return to normal/control mode				opliance.	

8.0 Table of error codes

Error code	Defective component	Emergency mode
F3	IAIT SANSOT	In the case of a sensor error the appliance goes into continuous mode.